

VALVE BOX ADAPTOR II INSTALLATION PROCEDURES

ADAPTOR

Step One

Identify the valve type (AFC, Mueller, Kennedy, Clow, EJ, etc.) and size (2" to 16"). Then select the proper Valve Box Adaptor II (VBA-II) to match the valve.



Step Two and Three

Insert VBA-II into the bottom of the valve box and push down until securely in place.



Step Four and Five

Place valve box and VBA-II onto bonnet of valve, push down until securely in place.



CALL OR VISIT OUR WEBSITE TO LEARN MORE

2151 South 54th Street, West Allis, WI 53219 • office 414.764.6733 • fax 414.764.1494 • adaptorinc.com •  American Made